

Flat Panel Surface Mount Installation Guide



This surface mount kit is suitable for Verbatim 2 ft. x 2 ft. (600mm x 600mm) LED Panels. Carefully read all instructions and product labels prior to installation. Also refer to the instructions and safety information included with the Verbatim LED Panels.

Includes:

- (4) Frames
- (4) Corner brackets
- (16) Short screws to assemble frames
- (16) Screw covers
- (8) Long screws to fix the kit to ceiling
- (8) Screw anchors
(includes extra, not all are required for installation)



Figure 1

Installation Instructions

1. Assemble the four frames using the corner brackets and short screws to create a square box (See Figure 1).
2. Hold the box against the ceiling and mark the position of the screw holes on three sides only.
**Leave the fourth frame open to insert the LED panel in Step 5. Ensure that the space next to unfixed frame has enough space to slide the LED panel into the kit. **
3. Drill holes according to the marks and affix the kit to ceiling with long screws on three sides.
4. Remove the non-fixed frame by unscrewing frames and connectors.
5. Slide the LED panel partly into the kit. Connect the driver to the power supply.
** Refer to the instructions and safety information included with the LED panel. **
6. Slide the LED panel fully into the frame. Affix the last frame and close the kit.

NOTE: The last frame is NOT screwed to the ceiling.

Warranty and Support

Verbatim 5-Year Limited Warranty (www.verbatimlighting.com/warranty)

For support, visit: www.verbatimlighting.com/support