INSTRUCTIONS
LED T8 U-Bent Series

RAB Lamps

RAB Lighting is committed to creating high-quality, affordable, well-designed and energy-efficient LED lighting and controls that make it easy for electricians to install and end users to save energy. We'd love to hear your comments. Please call the Marketing Department at 888-RAB-1000 or email: marketing@rablighting.com

U6-15-8XX-DIR



SAFETY PRECAUTIONS

WARNINGS:

- **Make certain power is OFF before installing or maintaining fixture.**
- **RISK OF FIRE.** USE ONLY IN PLACE OE FLUORESCENT LAMPS SPECIFIED ON LABEL.
- **RISK OF ELECTRIC SHOCK.** SUITABLE FOR DAMP LOCATIONS.

SAFETY INFORMATION:

(1) Check the lamp before installation, if there is any damage caused during transportation, do not install.
(2) Maintenance should be carried out by technical personnel only.
(3) Do not stare at the light source with bare eyes for a long time, or beam to others' eyes.
(4) Do not place any objects on the lamp.
(5) Keep the lamp away from flame or high temperature objects.
(6) Only replace with same type of LED tube! Risk of electrical shock!
(7) If the glass lamp tube is broken, the lamp must be disposed of immediately!


LED T8 lamp for use only with products described and installed in accordance with product specifications. LED T8 lamp to be operated with fluorescent electronic ballast.


PRODUCT FEATURES

- UL certified
- Plug-n-Play replacement
- Full glass housing: no aging, yellowing, bending
- Compatible with programmed start electronic ballasts
- Product applications: widely used in residential buildings, offices, shopping malls, supermarkets, hospitals, assembly lines, warehouses, etc. for energy-saving illumination.

INSTALLATION INSTRUCTIONS


1) Make Sure power is OFF
2) Remove lens or diffuser (if applicable)
3) Remove existing fluorescent lamps from the luminaire







INSTALLATION INSTRUCTIONS *(cont'd)*

4) Bring LED lamp to luminaire, ensure that the LED lamp front points away from the back of the luminaire and insert lamp pins into luminaire lamp holders.





5) Insert lamp holder that on the other side of lamp pins into metal hook of the luminaire.



6) Place lens or diffuser back in place (if applicable)
7) Power ON.

INSTRUCTIONS
LED T8 U-Bent Series

RAB | Lamps

RAB Lighting is committed to creating high-quality, affordable, well-designed and energy-efficient LED lighting and controls that make it easy for electricians to install and end users to save energy. We'd love to hear your comments. Please call the Marketing Department at 888-RAB-1000 or email: marketing@rablighting.com

MAINTENANCE NOTES

- Disconnect lamp from power supply before any maintenance.
- Clean luminaire with dry cloth.
- Do not clean the lamp with corrosive chemicals.
- NOT FOR EMERGENCY LIGHTING.

WARNING

DO NOT INSTALL THIS LAMP IN A PRE-HEAT LUMINAIRE.

NOT SUITABLE FOR ENCLOSED LUMINAIRES.

THIS LAMP ONLY OPERATES ON ELECTRONIC BALLASTS.
If lamp does not light when the luminaire is energized, remove lamp from luminaire and contact lamp manufacturer or qualified electrician.

CAUTION RISK OF FIRE. If the lamp or luminaire exhibits undesirable operation (buzzing, flickering, etc.), immediately turn off power, remove lamp from luminaire and contact manufacturer.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

© 2019 RAB LIGHTING Inc.
Northvale, New Jersey 07647 USA

Easy Answers

rablighting.com
Visit our website for product info

Tech Help Line
Call our experts: 888 722-1000

e-mail
Answered promptly - sales@rablighting.com

Free Lighting Layouts
Answered online or by request

RAB WARRANTY: *RAB's warranty is subject to all terms and conditions found at rablighting.com/warranty.*